

MY LITTLE STORE

ACCESSORIES & MORE

Manual for installation of Trailer Cover Support Bars

Step 1:

Place the shoulder brackets on both sides of the trailer.
Make sure they are level and aligned with each other.
Mark the screw holes.
Drill pilot holes slightly smaller than the screws.



Step 2:

Use the provided screws to install the shoulder brackets.



Step 3:

Align the pre-drilled holes on the outer bar with the predrilled holes on the bracket. Insert the supplied bolt through the holes, fit the nut, and tighten securely.



Step 4:

Next, slide the narrower tube into the outer tube. Pull it back until it covers the width of the trailer and the pre-drilled holes line up with the bracket. Insert the provided bolt, fit the nut, and tighten securely.

Step 5:

Finally, tighten the bar using the flower nut to lock it in place and keep it at the correct length.

The Final Product Should look like this when assembled.



**Thanks for using
our product!**

For any help related to the installation of this product, please contact:

help@mylittlestore.com.au

+61 432 995 966

**We are not accountable for damage to any
product if this instructional manual was not
followed properly during installation.**