

MY LITTLE STORE

ACCESSORIES & MORE

Manual for installation of Trailer Cover Support Bars

Step 1:

Use the Shoulder Brackets to mark where to drill into the trailer, and make sure both sides of the shoulder brackets are aligned. Once marked, drill carefully, ensuring to keep the hole at a thickness a little less than the thickness of the provided screws.



Step 2:

Use the provided self-tapping screws to install the shoulder brackets.



Step 3:

Next, slide both L shaped ends into the main tube.



Step 4:

Now, put the **shaved part** of the L shaped end into the bracket installed from step 1 and 2.



Step 5:

Use the provided black screws to tighten the L shaped ends to the main tube.

Step 6:

Finally, use the same screws to tighten the bar to your preferred height.

The Final Product Should look like this when assembled.



**Thanks for using
our product!**

For any help related to the installation of this product, please contact:

help@mylittlestore.com.au

+61 432 995 966